

How to use the: Model 3000D Professional

STEAM VAPOUR AND VACUUM SYSTEM
WITH WATER FILTER (WET/DRY) AND DETERGENT INJECTION



START UP

1. Check the water reservoir and fill if necessary.
2. Remove the blue cover.
3. Open waste bucket and pour water up to indicated level (approx 2cm).
4. Fill detergent reservoir (optional).
5. Replace the blue cover.
6. Lift flap next to on/off button and push the connector hose into the socket until it clicks.
7. Attach the extension pipes and/or desired cleaning head.
8. Plug the machine in and turn on.
9. Wait until the green indicator light is on (4-5 mins).
10. Proceed to use the machine.

STEAM

1. To **start** steam pull trigger on the handle.
2. To **increase steam** volume press and hold the red steam button on handle - keep holding to return to low steam.
3. To **start the vacuum**, press the white vacuum button on the handle, then release - to increase power hold down the white vacuum button.
4. To **start the detergent** press the green detergent button on the handle, then release. To **stop** press the green detergent button again.
5. When '**alarm for lack of water**' lights, steam will stop. Undo the water cap and fill with clean, cold water - replace the cap and continue.

CLEAN UP

1. **Turn off** and unplug the machine.
2. Remove the hose (optional). To remove the hose, push the red button on the hose connector with thumb and pull gently.
3. Remove the blue cover.
4. Take out the waste bucket, remove the filters.
5. Wash the waste bucket, filters and the lid thoroughly.
6. Replace the filters and the bucket into the machine cavity.
7. Replace the blue cover.
8. Wash the attachments and hoses.
9. Store the machine in a dry, safe place.




STANDARD ACCESSORIES



- 31 - floor brush 30cm long
- 31B - frame with double rubber profile
- 31C - frame with double tubular profile
- 31A - frame with double bristle profile
- 32 - small brush 15cm
- 32A - 15cm frame with double bristle
- 32B - frame for windows 15cm
- 32C - frame for windows 25cm
- 34 - multi-use mouth
- 34B - trapezoid mouth
- 34D - brush polyester 30mm diameter
- 34E - brush steel 30mm diameter
- 34F - brush polyester 60mm diameter
- 33 - sponge covering with elastic 15cm
- 34G - black spatula
- 34A - vertical mouth
- 29 - extension hose 44cm long
- 34C - ferrule with fixed extension
- 35 - pipe spanner for boiler draining
- 17 - flexible hose 2.45m long

OPTIONAL ACCESSORIES



- 23 - carpet beater
- 24 - armchair beater
- 26 - transparent mouth 10cm
- 11 - small sink plunger
- 12 - brush polyester 60mm diameter
- 14 - brush polyester 38mm diameter
- 16 - brush brass 38mm diameter
- 15 - brush steel 38mm diameter
- 7 - sponge covering with elastic 30cm
- 22 - water bottle
- 49 - flexible hose 5m long
- 41 - big brush with polyester bristles
- 42 - big brush with steel bristles
- 43 - big brush with brass bristles
- 50 - trolley