

Cimex Eradicator



- Safety cap.
- Steam nozzle with worldwide Polti patented controlled expansion chamber up to 180° C overheated dry steam outflow.
- Connection for HPMed sanitizing solution single-use bottle placed under the steam nozzle.
- Integrated spacer/stand.
- Ergonomic handle with soft-touch insert.
- Steam release button with safety lock device.

Cimex Eradicator vs bedbugs



cimex ERADICATOR+

Cimex Eradicator is the technological and ecological solution for the elimination of bedbugs.



Laboratory and field tests show that the flow of overheated steam, generated by Cimex Eradicator, can eliminate 100% of the eggs* and a very high proportion of the mobile insects with a single treatment.

- No contact with surfaces
- It removes the bad smell of bedbugs

System	Pressurized boiler
Max pressure	4 bar
Pressure switch	Yes
Pressure gauge	Yes
Steam output	Up to 110 g/min
Steam adjustment	Continuous
Boiler material	Stainless steel
Boiler volume	2,9 l
Use capacity	2 l
Steam ready indicator	Yes
Low water level indicator	Yes, acoustic
Vacuum function	No
Parking System	No
Boiler power	1500 W
Nozzle power	750 W
Max power	2250 W
Dimensions (WxDxH)	Ø 36 x 42 cm
Weight	4,9 kg

*Proven by Pest 2000 – Pest 3000, Italy

FEATURES



DESTROYS 100% OF BED BUGS*

At the first treatment destroys 100% of the eggs and more than 90% of the adult insects.



RAPID ACTION IN FEW SECONDS

A single treatment at a speed of 10 cm/sec can eliminate all the eggs present and almost all of the insects*.



OVERHEATED DRY STEAM UP TO 180° C

The flow of steam at 180° C can eliminate the adult insects, the larval stages and the eggs because it causes thermal shock.



WITHOUT USE OF INSECTICIDES

The overheated dry steam does not release toxic substances and can even be emitted in the presence of people.



SAFETY CAP

Technology for safety. Vaporetto's cap cannot be opened until there is minimal residual pressure in the boiler.

ACCESSORIES



HpMed for Steam Disinfectant
An adjunct to the action of steam sanitization, also contributes to the elimination of odours. **2 single-use phials.**



Flow concentrator
Specific accessory for sanitizing the toilet or the hardest to reach corners.



Quick guide
Guide to dis-infestation and Demo DVD.



Cleaning brush for the steam nozzle
For cleaning the nozzle.



Protective gloves
with non-slip finish.



Filling bottle